



**AMIDE FREE SHAMPOO
ETB577**

INGREDIENTS	INCI NAME	
Water	Water	34.3%
Rhopadex EA-2	Ammonium Laureth Sulfate	50.0%
Rhodapon L-22	Ammonium Lauryl Sulfate	10.0%
Mirataine BET-C 30	Cocamidopropyl Betaine	5.0%
Hetoxamate 6000 DS Special	PEG-150 Distearate	0.5%
Mackstat DM	DMDM Hydantoin	<u>0.2%</u>
		100.0%

PROCEDURE

- 1) With adequate mixing, combine the first 3 ingredients and begin heating to 70C.
- 2) Add the Hetoxamate 6000 DS Special and continue heating to 80C.
- 3) Add the Mirataine BET-C 30 and maintain at 80C for ten minutes.
- 4) Reduce mixing speed and begin cooling to room temperature.
- 5) Add the Mackstat DM at 40-45C and continue cooling.

Global Seven, Inc. believes the information contained in this literature to be reliable, but it is only representative information. No warranty is given or implied as to accuracy, suitability for particular applications or the results to be obtained. This is not a commercialized product and has not been the subject of extensive testing for efficacy, stability, performance or safety. No recommendation should be construed as inducement to infringe patents.